Language: English
Final size: 7.5cm x 8.5cm closed, 15.0cm x 8.5cm open
Format: 4 panel fanfold
Stock:
Ink:
Fonts supplied:
Film:
Author & coordinator:
Design & production:

Panel 2, Inside front cover

Fold

Panel 3, Inside back cover

DECT Handset 4060 information

For detail on the features of this handset, refer to the *Nortel Networks DECT Handset 4060 User Guide*.

Safety information

Do not rely on a cordless handset in emergencies.

Never use your handset in:

- the vicinity of electrical detonators
- shielded rooms
- areas where radio transmission is forbidden
- aircraft

Do not place your handset near:

- water, moisture, or damp areas
- heat sources, direct sunlight, or unventilated areas
- devices that generate strong magnetic fields
- areas with excessive dust, shock, or temperature

Legend

<option> Angle brackets require you to use the arrow keys to select the given option.

Handset on	for longer than 2 seconds
Handset off	for longer than 2 seconds
Keypad lock	Menu #
Keypad unlock	#
Muting	In conversation
Making a call:	
Off-hook	enter number
On-hook	Enter number
Telephone Book	<number>
Redial List	<number>
Caller List	<Caller List> <number>
Answering a call	
Call Transfer	<number>
Terminating a call	

Fold

Modifying your Telephone Book:	
Add	Options <New> enter number, enter name
Edit	<name> Options Edit OK
Delete	<name> Options Delete OK

Adjusting the ringer settings:	
Ringer type	Menu<Ringer Settings><Type>OK
Ringer volume	Menu<Ringer Settings><Volume>OK
Buzzer on/off	Menu *
Vibrator on/off	Menu<Ringer Settings><Device>OK
Headset on/off	Menu<Ringer Settings><Device>OK
Mute incoming call	Silence

Copyright © 2007 Nortel Networks. All rights reserved
Document Number: NN43120-104
Document Release: December 2007 Standard 01.01

DECT Handset 4060
Quick Reference Card

To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.

NORTEL

Panel 4, back cover

Fold

Panel 1, front cover